

# SUBMINIATURE BULKHEAD JACKS 150/3150 SERIES TRS/TTM

*BJ157 Shown*

**BULKHEAD JACK**  
FRONT MOUNT, SOLDER POT

3-lug **BJ157**  
4-lug **BJ157FL**  
Threaded **BJ3157**  
Mounting Hole: D6.187

(Hermetically sealed version available, pg. 13)

*BJ158 Shown*

**FEED-THROUGH JACK**

3-lug **BJ158**  
4-lug **BJ158FL**  
Threaded **BJ3158**  
Mounting Hole: D5.190/D4.190 (Threaded)

**BULKHEAD JACKS**  
FLANGE MOUNT, SOLDER POT

3-lug **BJ157F- $\triangle$**   
4-lug **BJ157FFL- $\triangle$**   
Threaded **BJ3157F- $\triangle$**

*BJ155 Shown*

**INSULATED BULKHEAD JACK**  
REAR MOUNT, SOLDER POT

3-lug **BJ155**  
4-lug **BJ155FL**  
Threaded **BJ3155**  
Mounting Hole: D9.148

**HOLE CONFIGURATION:**

Dim	# of holes/ Type-Dimension	
A Dim = .425	2/Clear- .103" diameter	- 2C(S)
	2/Threaded-.099-56UNF-2B	- 2T(S)
B Dim = .687	4/Clear- .103" diameter	- 4C(S)
	4/Threaded-.099-56UNF-2B	- 4T(S)

(S) = Comes with Stainless Steel Phillips #3-56 Pan Head Screws  
Maximum Panel Thickness .187

*BJ154-29 Shown*

**INSULATED BULKHEAD JACK**  
REAR MOUNT, WRENCH CRIMP

3-lug **BJ154- $\triangle$**   
4-lug **BJ154FL- $\triangle$**   
Threaded **BJ3154- $\triangle$**   
Mounting Hole: D9.116

*BJ152 Shown*

**INSULATED BULKHEAD JACK**  
FRONT MOUNT, SOLDER POT

3-lug **BJ152**  
4-lug **BJ152FL**  
Threaded **BJ3152**  
Mounting Hole: D9.208

*BJ154AC-207 Shown*

**INSULATED BULKHEAD JACK**  
REAR MOUNT, TOOL CRIMP

3-lug **BJ154AC- $\triangle$**   
4-lug **BJ154ACFL- $\triangle$**   
Threaded **BJ3154AC- $\triangle$**   
Mounting Hole: D9.116

*BJ150 Shown*

**BULKHEAD JACK**  
REAR MOUNT, SOLDER POT

3-lug **BJ150**  
4-lug **BJ150FL**  
Threaded **BJ3150**  
Mounting Hole: D4.250

*BJ153 Shown*

**INSULATED FEED-THROUGH JACK**

3-lug **BJ153**  
4-lug **BJ153FL**  
Threaded **BJ3153**  
Mounting Hole: D9.116

$\triangle$  - Refers to the cable group table see pages 68-88. "D" Mounting holes see page 45.  $\triangle$  - Replace with item from related table (same page).